Original		Sustituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	[ ]/[+]	PROGRAM TV/RADIO	TV/Radio /
	Input	RDS AV INPUT	AV / Input / RDS
	[=]	GOTO TEXT	Text / Goto
	[X]/[o]	SIZE ZOOM	Zoom / Size
	[♦]	FORMAT PICTURE	Picture / Format
	[?]/[i+]	EQ SUBTITLE	Subtitle / EQ
	↔	LIST SMART	Smart / List
	[II]/[=i]	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Sustituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
+/-	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
C	C	PC FAV MARKER	Fav / Marker / PC
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
MENU	Menu	HOME MENU	Menu / Home
+	+		Up
-	-		Down
→←	→←	OK	OK
+	Vol +	+ VOL	Vol +
-	Vol -	VOL -	Vol -
+	Progr +	+ CH PAGE	CH+ / Page+
- PROGR	Progr -	CH PAGE -	CH- / Page-

Original	Sustituto	Original	Sustituto
Power VTR1	SHIFT + Power		
>> VTR1	TUNE+ >> / Tune+		
Play VTR1	SLOW Play / Slow		
<< VTR1	TUNE- << / Tune-		
Stop VTR1	HOLD Stop / Hold		
Pause VTR1	STEP-FREEZE Pause / Step / Freeze		
Rec VTR1	REC MODE Rec / Rec Mode		
PROGR + VTR1	SHIFT + CH PAGE + Shift + CH+ /		
PROGR - VTR1	SHIFT + CH PAGE - Shift + CH- /		

Original	Sustituto	Original	Sustituto
Power VTR2	Power		
Progr + VTR2	CH+ / Page+		
Progr - VTR2	CH- / Page-		
Play VTR2	Play / Slow		
>> VTR2	>> / Tune+		
<< VTR2	<< / Tune-		
Stop VTR2	Stop / Hold		
Pause VTR2	Pause / Step / Freeze		
Rec VTR2	Rec / Rec Mode		

Original		Sustituto	
	Power VTR3		Power
	Play VTR3	SLOW	Play / Slow
	>> VTR3	TUNE+	>> / Tune+
	<< VTR3	TUNE-	<< / Tune-
	Stop VTR3	HOLD	Stop / Hold
	Pause VTR3	STEP-FREEZE	Pause / Step / Freeze
PROGR +	Prog+ VTR3	CH PAGE +	CH+ / Page+
PROGR -	Progr- VTR3	CH PAGE -	CH- / Page-
	Rec VTR3	REC MODE	Rec / Rec Mode

Original	Sustituto

Original	Sustituto	Original	Sustituto
Power MDP	Power		
Play MDP	Play / Slow		
>> MDP	>> / Tune+		
<< MDP	<< / Tune-		
Stop MDP	Stop / Hold		
Pause MDP	Pause / Step / Freeze		
Progr+ MDP	CH+ / Page+		
Progr- MDP	CH- / Page-		