Mandis shop

Sveon SBX442

Original		Sustituto	
	Power		Power
	Play / Pause	PLAY MODE	Play
	Play / Pause		Pause
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	I<<		I<<
	>>I		>>I
	Vol -	VOL –	Vol -
	Vol +	+ VOL	Vol +
HOME	Home	HOME SMART	Smart
BACK	Back	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
MOUSE	Mouse	APP MEDIA	Media
1	1	1	1
2	2	2	2

Original		Sustituto	
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0	0	0	0
	Mute	MUTE	Mute
DELET	Delet	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

https://mandisshop.es/es/Sveon/1568-932-mando-sustituto-para-Sveon-SBX442.html