Original	Sustituto
Power	Power
Open / Close	Eject
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Audio	Dual
Subtitle	Subt
Angle	Format
Menu	Menu

Original	Sustituto
Title	Smart
[--]	Media
Exit	Exit
Up / >>	>>
Up / >>	Up
Left	Left
OK / Play	Ok
OK / Play	Play
Right	Right
Down / <<	<<
Down / <<	Down
▲ / >>I	>>I
▲ / >>I	Ch +
▼ / I <<	I <<
▼ / I <<	Ch -
Stop	Stop
Pause	Pause

Original	Sustituto	Original	Sustituto
Repeat 1- ALL	REPEAT TEXT Text		
Repeat A- B	SHIFT + PLAY MODE Shift + Play		