Mandis shop

Pioneer AXD7738

Original	Rechange	Original	Rechange
Standby/on	Power	Vol +	Vol +
Open/Close	Eject	Vol -	Vol -
Disc/Bluetooth	Smart	Mute	Mute
FM	Green	P. Bass	Back
USB/Audio In	Red	Repeat/Shuffle	Text
Preset/Album	Up	Dimmer/Display	3D
Preset/Album	Down	Program	Shift + Sleep
>>I / >>	Right	EQ	Dual
>>	>>	Clock	AV
>>I	>>I	Sleep/Timer	Sleep
I <<	I <<		
<<	<<		
I <</ <<	Left		
Play/Pause	Ok		
Pause	Pause		
Play	Play		
Stop	Stop		

https://mandis.com/fr/Pioneer/1568-699-telecommande-replacement-pour-Pioneer-AXD7738-501.RXM2FRhtm