Mandis shop

Samsung DJ96-00114G

Original		Rechange	
Power	Power	Power	Power
Recharging	Recharging	Aspect / Eco	Eco / Aspect
Auto	Auto	Auto	Auto
Spot	Spot	Source	Source
Max	Max	Mode	Mode
	Up		Up
	Right		Right
	Left		Left
Start/Stop	Start/Stop	Enter	Enter
Manual	Manual	Video / Comp	Comp / Video
Edge	Edge	Page▲ / Vol	Vol + / Page +
Clock	Clock	Menu	Menu
Timer/Daily	Timer/Daily	Timer / Freeze	Freeze / Timer
	No Name Left	Play	+ / Play
	No Name Right	Focus / Volt	Volt / Focus

Original	Rechange

https://mandisremotes.com/fr/Samsung/1059728-79362-telecommande-de-remplacement-pour-Samsung-DJ96-00114G.html