Mandis shop

MORE001

Original		Rechange		Original	Rechange
ON/OFF	On/Off		Power		
TIMING	Timing	TIMER SLEEP	Sleep / Timer		
NIGHT LIGHT	Night Light	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II		
COLOR LIGHT	Color Light	RETURN BACK	Back / Return		
ROTATION	Rotation	MEDIA DISPLAY	Display / Media		

https://mandis-notes.com/fr/Moredig/106644-9649-telecommande-replacement-pour-Moredig-MORE001.htm