Mandis shop

RB- ZX350

Original	Rechange	Original	Rechange
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Skip/Search	>>I / Preset +		
I <<	I << / Preset -		
Memory	OK		
Repeat	Green / APP / Repeat		

https://mandis-shop.com/fr/Sanyo/1625-305-telecommande-de-remplacement-pour-Sanyo-RB-ZX350.htm