Original	Rechange	Original	Rechange
Power	Power	Pause	Pause
Mute	Mute	Menu	Menu
1	1	Exit	Exit
2	2	Digest	Options
3	3	FAV	Pre Ch
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	OK	Ok
9	9	Scan	Smart
0	0	Edit	3D
Tv/Radio	TV/R	EPG	Guide
Recall	Back	Red	Red
i	Info	Green	Green
L/R	Media	Yellow	Yellow
Play	Play	Blue	Blue

Original		Rechange		Original		Rechange	
AUDIO	Audio	SOUND DUAL	Dual				
SUBTITLE	Subtitle	AD SUBT	Subt				
TTX	TTX	REPEAT TEXT	Text				