Mandis shop

RC-601

Original		Rechange	
IN	IN		Up
IN	IN	CH	CH+ / Page+
IN	IN		Right
IN	IN	VOL	Vol+
OUT	OUT		Down
OUT	OUT	CH	CH- / Page-
OUT	OUT		Left
OUT	OUT	VOL	Vol-

Original	Rechange

https://mandisremotes.com/fr/LAVA/1068113-27978-telecommande-de-remplacement-pour-LAVA-RC-601.html