Mandis shop

Pioneer CU-PD024

Original	Rechange
Open/Close	Eject
Play	Play
Stop	Stop
Pause	Pause
Repeat	Text
Random Play	TV/R
Manual >>	>>
<< Manual	<<
I << Track	I <<
Track >>I	>>I
< Index	Left
Index >	Right
1	1
2	2
3	3
4	4
5	5

Original	Rechange
6	6
7	7
8	8
9	9
10	0
+10	Guide
≧20	Pre Ch
Clear	Exit
Check	Smart
PGM	Sleep
Time	AV