Original	Rechange	Original	Rechange
Standby	Power	Timer	AV
Teletex	Text	Menu	Menu
Red	Red	Mute	Mute
Green/[ ] Smart	Green	P<P	Pre Ch
Yellow/♪ Smart	Yellow	OK	Ok
Blue	Blue	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	P+	Ch +
5	5	P-	Ch -
6	6	Vol +	Vol +
7	7	Vol -	Vol -
8	8	Play	Play
9	9	Stop	Stop
0	0	Record/OTR	Rec
Clear	Exit	<<	<<

Original		Rechange		Original	Rechange
	>>		>>		
INDEX	>I / Index		>>I		
STILL	>I </ Still		Pause		